

Since 1975
Randy's
 Alt. Culture Pioneers

DRIFT 2.0

THIS PRODUCT DOES NOT CONTAIN TOBACCO OR NICOTINE. NOT INTENDED FOR TOBACCO USE. FOR USE WITH LEGAL HERBS ONLY. Make sure to keep out of the reach of children and/or unqualified persons.

Cover

KIT INCLUDES / OPERATING

- **DRIFT 2.0**
- **510 THREAD CHARGER**
- **DUAL QUARTZ COIL**
- **METAL TOOL**
- **GLASS MOUTHPIECE**
- **SILICONE DEBRIS SCREEN**

The Drift 2.0 is specifically designed to combust your desired dry herb. The 3 variable voltage settings are designed to offer a wide range of experiences for any user. The Drift 2.0 uses rapid heat technology to heat your dry herb to the desired temperature in just 3 seconds. Your device also comes equipped with a built in silicone storage jar at the base of the battery. This is designed to provide ultimate portability and convenience for that user.

Page 2

COMPONENTS/ANATOMY

Page 4

CONNECT WITH OUR SOCIALS

- @RANDYSPAPERS**
- @RANDYSPAPERS**
- @RANDYSWIRED**
- @RANDYSWIRED**
- @RANDYSWIRED**

Page 6

LIMITED WARRANTY INFO

Randy's offers 2 types of warranty on all of our vaporizers!

Limited Warranty - 1 Year

Covers defects that may be present such as electrical components.

Limited Component Part Warranty - 1 Year

Covers damages involving glass, coils and/or mouthpieces.

Visit: Randys.com/warranty for more info!

Since 1975
Randy's
 Alt. Culture Pioneers

Page 6

INTRODUCTION

Thank you for purchasing the Randy's Drift 2.0! Please read and follow the instructions carefully. Understand them fully before your first use. It is recommended that these instructions are put into a safe place for future reference. We hope that you enjoy the quality and performance of your new Drift 2.0 vaporizer.

You must be over 21 years old to purchase and use the Randy's Drift 2.0. This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor!

Randy's Drift 2.0 is not a medical device and is not intended to diagnose, cure, treat, or prevent any diseases or other conditions. If you have any health problems, consult your doctor before using. Randy's Drift 2.0 is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties and/or imprisonment under law of your jurisdiction.

Page 1

SPECIFICATIONS/CHARGING

Battery Capacity: 650mAh
Working Voltage: 3.2v - 4.2v
Resistance: 0.8ohm
Pen Size: 14mm x 140mm
Tank Size: 14mm x 60mm
Battery Size: 14mm x 80mm
Charging Time: 1-2 hours

To Turn on/off: Press the button 5 times

To Change Temp: Press the button 3 times

To Charge Drift 2.0: Unscrew the coil so just the battery and 510 thread is showing. Screw the included Drift 2.0. Plug the charger into a wall adapter.

DO NOT LEAVE THE DEVICE UNATTENDED WHILE CHARGING. ONLY USE THE INCLUDED CHARGER FOR YOUR DEVICE.

Page 3

OPERATING INSTRUCTIONS

Step 1: Carefully remove Mouthpiece. Make sure the glass is cooled off first.

Step 2: Load material into Drift 2.0 coil. Make sure to load, evenly ground material.

Step 3: Click the button 5 times to turn on.

Step 4: Select your desired Temp Setting. 3 clicks of the button to cycle settings.

Step 5: Press button for at least 3 seconds as device begins to heat up.

Temperature Settings:

Red Light - (3.2V) Will produce 420°F - 580°F in 6-8 seconds

Blue Light - (3.7V) Will produce 600°F - 760°F in 4-5 seconds

White Light - (4.2V) Will produce 780°F - 920°F in 3 seconds

WARNINGS: PLEASE READ BEFORE USE.
 Caution: Device may be hot after use. Turn the device off when not in use. When cleaning debris from coil, be cautious of scraping the metal on the coil. This may cause permanent damage.

Page 5

TROUBLESHOOTING

No vapor being produced:

1. Ensure device is turned on.
2. Make sure battery is charged.
3. Make sure coil is secure to battery.
4. Make sure device is not overloaded.

Regular maintenance and cleaning of your Drift 2.0 is highly recommended.

Do not use the Drift 2.0 if the walls or mouthpiece become chipped, cracked or broken.

If you lose any part or need a replacement, visit the ship where you purchased the device or you can shop Randys.com

HAVE AN ISSUE?

EMAIL: SALES@RANDYS.COM AND WE WILL GET YOU TAKEN CARE OF!

Page 7

WARRANTY CLAIM INSTRUCTIONS

To file a claim online:

Randys.com/warranty or Email: Sales@Randys.com

We can not replace any unit or part without a proof of purchase. Warranty claims usually take 2-3 weeks to process.

Please Return to: Randy's Warranty, P.O. Box 1253, Holland, OH 43528

Send us:

1. The defective part (Please only send parts that are defective and clean)
2. A copy of your proof of purchase
3. A copy of proof of legal age
4. A note detailing the issue(s)
5. Return address

WARNING: This product can expose you to chemicals including Cadmium, which is known to the State of California to cause cancer, and Cadmium, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Page 7